RCA

Television User's Guide

Models: 14B042 / 21B042

Please read these instructions before operating this product for the first time.

TOCOM 1640641B

Changing Entertainment. Again.



Downloaded from www.Manualslib.com manuals search engine

Important Information

CAUTION

RISK OF ELECTRIC SHOCK
DO NOT OPEN

This symbol indicates that this product incorporates double insulation between hazardous mains voltage and user accessible parts. When servicing use only identical replacement parts.

This symbol indicates "dangerous voltage" inside the product that presents a risk of electric shock or personal injury.

This symbol indicates important instructions accompanying the product.

WARNING

To reduce the risk of fire or electric shock, do not expose this product to rain or moisture.

The apparatus should not be exposed to dripping or splashing and no objects filled with liquids, such as vases, should be placed on the apparatus.

CAUTION

FCC Regulations state that unauthorized changes or modifications to this equipment may void the user's authority to operate it.



Caution: To prevent electric shock, match wide blade of plug to wide slot, fully insert.

Attention : Pour éviter les chocs électriques, introduire la lame la plus large de la fiche dans la borne correspondante de la prise et pousser jusqú au fond.

Power consumption (model 14B042): 90-140 volts AC, 50Hz/60Hz @ 70 watts.

Power consumption (model 21B042): 90-140 volts AC, 50Hz/60Hz @ 80 watts.

Caution: Using video games or any external accessory with fixed images for extended periods of time can cause them to be permanently imprinted on the picture tube (or projection TV picture tubes). ALSO, some network/program logos, phone numbers, etc. may cause similar damage. This damage is not covered by your warranty.

Cable TV Installer: This reminder is provided to call your attention to Article 820-40 of the National Electrical Code (Section 54 of the Canadian Electrical Code, Part 1) which provides guidelines for proper grounding and, in particular, specifies that the cable ground shall be connected to the grounding system of the building as close to the point of cable entry as practical.

Product Registration

Please fill out the product registration card (packed separately) and return it immediately. Registering this product allows us to contact you if needed.

Product Information

Keep your sales receipt to obtain warranty parts and service and for proof of purchase. Attach it here and record the serial and model numbers in case you need them. The numbers are located on the back of the product.

Model No. _____ Serial No. _____ Purchase Date: _____

Dealer/Address/Phone: _____

_____

Downloaded from www.Manualslib.com manuals search engine

IMPORTANT SAFEGUARDS

1. **READ INSTRUCTIONS** - All the safety and operating instructions should be read before the unit is operated.
2. **RETAIN INSTRUCTIONS -** The safety and operating instructions should be retained for future reference.
3. **HEED WARNINGS -** All warnings on the unit and in the operating instructions should be adhered to.
4. **FOLLOW INSTRUCTIONS -** All operating and use instructions should be followed.
5. **CLEANING -** Unplug this unit from the wall outlet before cleaning. Do not use liquid cleaners or aerosol cleaners. Use a damp cloth for cleaning the exterior cabinet only.
6. **ATTACHMENTS -** The manufacturer of this unit does not make any recommendations for attachments, as they may cause hazards.
7. **WATER AND MOISTURE -** Do not use this unit near water. For example, near a bathtub, washbowl, kitchen sink, laundry tub, in a wet basement, or near a swimming pool.
8. **ACCESSORIES -** Do not place this unit on an unstable cart, stand, tripod, bracket, or table. The unit may fall, causing serious injury, and serious damage to the unit.

8A. An appliance and cart combination should be moved with care. Quick stops, excessive force, and uneven surfaces may cause the appliance and cart combination to overturn.

9. **VENTILATION -** Slots and openings in the cabinet back or bottom are provided for ventilation, to ensure reliable operation of the unit and to protect it from overheating. These openings must not be blocked or covered. The openings should never be blocked by placing the unit on a bed, sofa, rug, or other similar surface. This unit should never be placed near or over a radiator or heat source. This unit should not be placed in a built-in installation, such as a bookcase, or rack unless proper ventilation is provided or the manufacturer's instructions have been adhered to.
10. **POWER SOURCE -** This unit should be operated only from the type of power source indicated on the rating plate. If you are not sure of the type of power supply to your home, consult your appliance dealer or local power company. For units intended to operate from battery power, or other sources, refer to the operating instructions.
11. **GROUNDING OR POLARIZATION -** This unit is equipped with a polarized alternating current line plug (a plug having one blade wider than the other). This plug will fit into the power outlet only one way. This is a safety feature. If you are unable to insert the plug fully into the outlet, try reversing the plug. If the plug still fails to fit, contact your electrician to replace your obsolete outlet. Do not defeat the safety purpose of the polarized plug.
    If your unit is equipped with a 3-wire grounding-type plug, a plug having a third (grounding) pin, this plug will only fit into a grounding-type power outlet. This too, is a safety feature. If you are unable to insert the plug into the outlet, contact your electrician to replace your obsolete outlet. Do not defeat the safety purpose of the grounding-type plug.
12. **POWER-CORD PROTECTION -** Power supply cords should be routed so that they are not likely to be walked on or pinched by items placed upon or against them, paying particular attention to cords at plugs, convenience receptacles, and the point where they exit from the appliance.
13. **LIGHTNING -** To protect your unit during a lightning storm, or when it is left unattended and unused for long periods of time, unplug it from the wall outlet and disconnect the antenna or cable system. This will prevent damage to the unit due to lightning and power line surges.
14. **POWER LINES -** An outside antenna system should not be located in the vicinity of overhead power lines, or other electric light or power circuits, or where it can fall into such power lines or circuits. When installing an outside antenna system, extreme care should be taken to keep from touching such power lines or circuits as contact with them might be fatal.
15. **OVERLOADING -** Do not overload wall outlets and extension cords as this can result in a risk of fire or electric shock.
16. **OBJECT AND LIQUID ENTRY -** Do not push objects through any openings in this unit as they may touch dangerous voltage points or short out parts that could result in fire or electric shock. Never spill or spray any type of liquid into the unit.
17. **OUTDOOR ANTENNA GROUNDING -** If an outside antenna or cable system is connected to the unit, be sure the antenna or cable system is grounded to provide some protection against voltage surges and built-up static charges. Section 810 of the National Electrical Code, ANSI/NFPA 70, provides information with respect to proper grounding of the mast and supporting structure, grounding of the lead-in wire to an antenna discharge unit, size of grounding conductors, location of antenna discharge unit, connection to grounding electrodes, and requirements for the grounding electrode.
18. **SERVICING -** Do not attempt to service this unit yourself as opening or removing covers may expose you to dangerous voltage or other hazards. Refer all servicing to qualified service personnel.
19. **DAMAGE REQUIRING SERVICE -** Unplug this unit from the wall outlet and refer servicing to qualified service personnel under the following conditions:
    a. When the power-supply cord or plug is damaged.
    b. If liquid has been spilled, or objects have fallen into the unit.
    c. If the unit has been exposed to rain or water.
    d. If the unit does not operate normally by following the operating instructions. Adjust only those controls that are covered by the operating instructions, as an improper adjustment of other controls may result in damage and will often require extensive work by a qualified technician to restore the unit to its normal operation.
    e. If the unit has been dropped or the cabinet has been damaged.
    f. When the unit exhibits a distinct change in performance, this indicates a need for service.
20. **REPLACEMENT PARTS -** When replacement parts are required, be sure the service technician uses replacement parts specified by the manufacturer or those that have the same characteristics as the original part. Unauthorized substitutions may result in fire, electric shock or other hazards.
21. **SAFETY CHECK -** Upon completion of any service or repairs to this unit, ask the service technician to perform safety checks to determine that the unit is in proper operating condition.
22. **HEAT -** The product should be situated away from heat sources such as radiators, heat registers, stoves, or other products (including amplifiers) that produce heat.
23. **NOTE TO CATV SYSTEM INSTALLER -** This reminder is provided to call the CATV system installer's attention to Article 820-40 of the NEC that provides guidelines for proper grounding and, in particular, specifies that the cable ground shall be connected to the grounding system of the building, as close to the point of cable entry as practical.

Example of Antenna Grounding as per (NEC) National Electrical Code


ANTENNA LEAD IN WIRE
GROUND CLAMP
ANTENNA DISCHARGE UNIT (NEC SECTION 810-20)
GROUNDING CONDUCTORS (NEC SECTION 810-21)
GROUND CLAMPS
ELECTRIC SERVICE EQUIPMENT
POWER SERVICE GROUNDING ELECTRODE SYSTEM (NEC ART 250, PART H)

Downloaded from www.Manualslib.com manuals search engine

Table of Contents

Important Safeguards 1
Front of the TV 3
Back and Side of the TV 3

Connections & Setup

Connecting to AC Power 4
Basic Operation 4
Antenna and Cable TV Connections 4
Connecting Other Components 6

Using the Remote Control

Buttons on the Remote Control 6

Using the TV's Features

TV Operation 8
Setting the Language 8
Setting Channels 9
Sleep Function 9

Using the Menu System

Navigating the Menus 10
Using the PICTURE menu 11
Using the P.LOCK menu 12
Using the TIMER menu 14
Using the PRESET menu 15
Using the EXTRA menu 16

Other Information

Troubleshooting 17
Specifications 17
Additional Jacks 17
Limited Warranty 18

Downloaded from www.Manualslib.com manuals search engine

Front of the TV

1. Power button
2. Power indicator
3. Remote sensor
4. TV/AV button
5. MENU button
6. Volume down button
7. Volume up button
8. Program down button
9. Program up button





Back and Side of the TV

10. Antenna jack
11. VIDEO INPUT jack
12. AUDIO INPUT jack (Mono)
13. AUDIO OUTPUT jack (Mono)
14. VIDEO OUTPUT jack
15. Side VIDEO INPUT jack (AV 2)
16. Side AUDIO INPUT jack (Mono) (AV 2)
17. Headphone

Notes:

The side AV jacks cannot be used with the rear AV2 jacks (AV on the 14B042) simultaneously.

Model 14B042 does not have AV OUT, AV2, or headphone jacks.



Downloaded from www.Manualslib.com manuals search engine



Polarized AC Cord Plug (One blade is wider than the other)

Connecting to AC Power

Use the AC polarized line cord provided for operation on AC. Insert the AC cord plug into a polarized AC outlet.

NOTE:
If the polarized AC plug does not fit into a nonpolarized AC outlet, do not attempt to fix or cut the blade of the plug. It is the user's responsibility to have an electrician replace the obsolete outlet.

Basic Operation

Plugging in the TV

Insert the power cord of the unit into a 90-140V AC outlet. Unplug the power when the unit will not be used for a long period of time.

How to Power On/Off

You can turn on the power by using the POWER button on the front of the TV (or the POWER button on the remote control).

Antenna and Cable TV Connections

Combination VHF/UHF Antenna (Single 75 ohm cable or 300 ohm twin-lead wire)
Connect the 75 ohm cable from a combination VHF/UHF antenna to the antenna jack. If your combination antenna has a 300 ohm twin-lead wire, use the 300-75 ohm matching transformer (not supplied).

Combination VHF/UHF Antenna (Separate VHF and UHF 300 ohm twin-lead)
Connect the UHF twin-lead wire to a combiner (not supplied). Connect the VHF twin-lead to the 300-75 ohm matching transformer (not supplied). Attach the transformer to the combiner. Attach the combiner to the antenna jack.

Separate VHF/UHF Antenna
Connect the 75 ohm cable from the VHF antenna and the UHF antenna twin-lead to a combiner (not supplied). Attach the combiner to the antenna jack.

Note: If your VHF antenna has a twin-lead wire, use the 300-75 ohm matching transformer (not supplied), then connect the transformer to the combiner.

Downloaded from www.Manualslib.com manuals search engine

For Subscribers to Basic Cable TV Service

For basic cable service not requiring a converter/descrambler box, connect the CATV 75 ohm coaxial cable directly to the antenna jack on the back of the television.

For Subscribers to Scrambled Cable TV Service

If you subscribe to a cable service which requires the use of a converter/descrambler box, connect the incoming cable to the converter/descrambler box and connect the output of the box to the antenna jack on the back of the television. Follow the connections shown below. Set the television to the output of the converter/descrambler box (usually channel 3 or 4) and use the converter/descrambler box to select channels.

For Subscribers to Unscrambled Basic Cable with Scrambled Premium Channels

If you subscribe to a cable service in which basic cable channels are unscrambled and premium channels require the use of a converter/descrambler box, you may wish to use a two-set signal splitter (sometimes called a "two-set coupler") and an A/B switch box from the cable installer or an electronics supply store. Follow the connections shown below. With the switch in the "B" position, you can directly tune any nonscrambled channels on your TV. With the switch in the "A" position, tune your TV to the output of the converter/descrambler box (usually channel 3 or 4) and use the box to tune scrambled channels.





Note:
This television has an extended tuning range and can tune most cable channels without using a cable company supplied converter box. Some cable companies offer "premium pay channels" in which the signal is scrambled. Descrambling these signals for normal viewing requires the use of a descrambler device which is generally provided by the cable company.

Downloaded from www.Manualslib.com manuals search engine

Connecting Other Components

The exact arrangement you use to interconnect various video and audio components to the TV is dependent on the model and features of each component. Check the Owner's Manual provided with each component for the location of video and audio inputs and outputs.

The connection diagrams below are offered as suggestions. You may need to modify them to accommodate your particular assortment of components. The diagrams are intended to show component video and audio interconnections only.

Press the TV/AV button to select the AV mode to use the TV as a monitor. Operate your VCR as usual.



TV/AV Selection

If you connect the TV to a VCR, camcorder or TV game, through the audio/video in jacks, use the TV/AV button to make your selection. Press the TV/AV button repeatedly to select the desired mode. "AUX" will display on the screen for 4 seconds.

To Connect the TV to a VCR



To Connect the TV to a Video Game System

The TV can also be used as a display device for many video games. However, due to the wide variety of different types of signal generated by these devices and subsequent hook-up variations required, they have not all been included in the suggested connection diagrams. You'll need to consult each component's Owner's Manual for additional information.



To Connect the TV to a Camcorder

To playback from the camcorder, connect the camcorder to the TV as shown.



Downloaded from www.Manualslib.com manuals search engine



Buttons on the Remote Control

(0-9) Number buttons Allows direct access to any channel. Two buttons must be pressed to select a channel when you set *ANTENNA* to *AIR*. For channels 2 through 9, press 0 first, then the channel number (for example, 02, 12). Three buttons must be pressed when you select a channel number under 20 if you set *ANTENNA* to *CABLE*, and for channels above 19, you can enter the three digits directly. For example, 001, 019, 20, 100.

CODE Allows you to change your P.LOCK (Parental lock) password (see page 12).

DISPLAY Displays the current channel information (such as channel, time, etc.). Press it again to exit.

FREE LISTEN This button has no function on this model.

MENU Displays the Main menu.

MUTE Reduces the TV's volume to its minimum level. Press again to restore the volume.

PICTURE Allows you to toggle the available picture settings: *DYNAMIC, SOFT, STANDARD,* and *PERSONAL*.

POWER Turns the TV on and off.

PROG. (PROGRAM) buttons △/▽ Press the △ button to go to the next channel in memory. Press the ▽ button to go to the previous channel in memory.

Q.VIEW (QUICK VIEW) Allows you to go back to the previous channel selected by just pressing the Q.VIEW button. Press again to return to your last channel.

TIMER Sets the sleep timer.

TV/AV Toggles between regular TV programming and the Video Input Channels (TV1/AV1/AV2).

VOL (VOLUME) buttons ◁/▷ Increases and decreases the volume.

Installing the Batteries

Before using the remote control for this first time, you need to install batteries.

1. Open the battery compartment cover.
2. Install two "AAA" batteries (not supplied).
3. Replace the battery compartment cover.

The batteries may last approximately one year depending on how much the remote control is used. For best performance, it is recommended that batteries should be replaced on a yearly basis, or when the remote operation becomes erratic. Do not mix old and new batteries or different types.

Battery Precautions

These precautions should be followed when using batteries in this device:

1. Use only the size and type of batteries specified.
2. Be sure to follow the correct polarity when installing the batteries as indicated in the battery compartment. Reversed batteries may cause damage to the device.
3. Do not mix different types of batteries together (e.g. Alkaline and Carbon-zinc) or old batteries with fresh ones.
4. If the device is not to be used for a long period of time, remove the batteries to prevent damage or injury from possible battery leakage.
5. Do not try to recharge batteries not intended to be recharged; they can overheat and rupture. (Follow battery manufacturer's directions.)

Downloaded from www.Manualslib.com manuals search engine

TV Operation

1. To turn on the TV, press the POWER button.
2. The VOLUME can be adjusted to a desired level by pressing the VOL (VOLUME)◁ or ▷button. The sound level will be indicated on the TV screen.
3. Set the ANTENNA menu option to the appropriate setting. When shipped from the factory, this menu option is set to *CABLE*. See "Setting Channels".

   TV - VHF/UHF channels
   CABLE - CABLE TV channels
4. **CH (CHANNEL) △/▽ buttons** Press and release the CH (CHANNEL) △ or ▽ button. The channel automatically stops at the next channel set into memory. Press and hold the button down to change channels more quickly.

   For proper operation, before selecting channels, they should be set into the TV's memory. See "Setting Channels".

   0-9 (Direct Channel Selection buttons) Press these buttons to select a channel. The channel number will appear on the upper right corner of the TV screen. If an invalid channel number is selected, the display will revert to the previous channel.

   TV mode direct channel selection When the *ANTENNA* menu option is set to *AIR*, all channels can be instantly selected by using two buttons (For example, to select channel 2, press "0", then "2". If you press only "2", channel selection will be delayed for a few seconds). For channels 10 and above, press the 2 digits in order.

   CATV mode direct channel selection When the *ANTENNA* menu option is set to *CABLE*, channels can be selected as follows:

1-9	Press "0" twice, then 1-9 as needed. For example, to select channel 2, press "002".
10-12	Press "0", then the remaining 2 digits. For example, to select channel 12, press "012".
13-99	Press the 2 digits in order. For example, to select channel 36, press "36".
100-125	Press the 3 digits in order. For example, to select channel 120, press "120".

   Note: If the station being viewed stops broadcasting, the TV will automatically shut off after 15 minutes.

Setting the Language

This TV can display the on screen displays and picture adjustments in English, Spanish or French.

1. Press the MENU button (the Main menu appears).
2. Press the PROG. △ or ▽ button to highlight *EXTRA*, then use the PROG. buttons again to highlight *LANGUAGE*.
3. Press the VOL ◁ or ▷ button to change the language to the desired setting: English (ENGLISH), Spanish (ESPAÑOL), or French (FRANCAIS).
4. Press the MENU button to exit.

   Note: If Spanish or French is chosen, the Closed Caption indicators will be in the selected language, but the Closed Caption text will not be affected by the language selection.

Downloaded from www.Manualslib.com manuals search engine

Setting Channels

This TV is equipped with a channel memory feature which allows channels to skip up or down to the next channel set into memory, skipping over unwanted channels.

Before selecting channels, they must be programmed into the TV's memory. In addition to normal VHF and UHF channels, this TV can receive up to 113 Cable TV channels. If you have an off-air antenna, set the *ANTENNA* menu option to *AIR*. When shipped from the factory, this menu option is set to *CABLE*.

1. Press the MENU button (the Main menu appears).
2. Press the PROG. △ or ▽ button to highlight *PRESET*, then use the PROG. buttons again to highlight *ANTENNA*.
3. Press the VOL ◁ or ▷ button to change the signal type to the desired setting: *CABLE* (cable TV) or *AIR* (off-air antenna).
4. Press the PROG. △ or ▽ button to highlight *AUTO PROGRAM*, then press the VOL ▷ button to begin auto channel search. This may take several seconds.

Adding / Deleting Channels

1. Press the MENU button (the Main menu appears).
2. Press the PROG. △ or ▽ button to highlight *PRESET*. *CH NO*. (Channel Number) is already highlighted.
3. Press the VOL ◁ or ▷ button or the number buttons to find the channel you want to add or delete.
4. Press the PROG. △ or ▽ button to highlight *CH* (Channel), then press the VOL ◁ or ▷ button to select *ADDED* or *DELETED*.
5. Repeat steps 2 - 4 for each channel to be added or deleted.

Sleep Function

1. Press the TIMER button on the remote control to display the set time 120, 90, 60, 30, 0 minutes for time-off. The unit automatically turns off when the set time has elapsed.
2. To cancel the sleep timer, press the TIMER button repeatedly until 0 is displayed.

Downloaded from www.Manualslib.com manuals search engine

Navigating the Menus

1. To enter a menu, press the MENU button, then use the PROG. △/▽ buttons to select the desired mode.
2. Press the VOL ◁/▷ buttons to select the mode you want to change.
3. Use the PROG. △/▽ buttons to select items within the submenu.
4. Use the VOL ◁/▷ buttons to change the settings.
5. Press MENU to return to the last menu.



Picture

The PICTURE menu will allow you to make adjustments to your picture settings.



P. Lock (Parental Lock)

You can set P.LOCK and V-CHIP in this menu.



Timer

The TIMER menu sets the clock on your TV and allows you to program your TV for scheduled viewing by using the ON/OFF timer.



Preset

The PRESET menu provides several options for your channel settings, including auto channel search and adding / deleting channels (see "Setting Channels" on page 9).



Extra

Set Closed Captioning, language, and background in this menu.

Downloaded from www.Manualslib.com manuals search engine

To select the PICTURE menu



Display ⟶ Highlight **PICTURE** ⟶ Select

◆ PICTURE	CONTRAST
P. LOCK	BRIGHT
TIMER	COLOR
PRESET	TINT
EXTRA	SHARPNESS

Using the PICTURE menu

CONTRAST

Adjust left to decrease picture contrast.

Adjust right to increase picture contrast.

Bright

Adjust left to darken the picture.

Adjust right to brighten the picture.

Color

Adjust left to decrease color intensity or saturation.

Adjust right to increase color intensity or saturation.

Tint

Adjust left to decrease the red tone.

Adjust right to increase the red tone.

Sharpness

Adjust left to soften the picture detail.

Adjust right to sharpen the picture detail.

Downloaded from www.Manualslib.com manuals search engine

To select the P.LOCK menu



Display ⟶ Highlight **P.LOCK** ⟶ Select



Figure 1



Figure 2



Using the P.LOCK (Parental Lock) menu

Note: When you enter the P.LOCK submenu for the first time, NEW CODE appears in red on the menu. Enter a four-digit number as your password by pressing the 0-9 buttons. After you enter the number, ENTER CODE appears in blue. Reconfirm your password by entering it again.

1. If you have already set your password and you want to enter the P.LOCK menu, *ENTER CODE* appears in blue, as shown in Figure 1. Enter your password.

Changing Your Password

1. If you need to change your password, press the CODE button when *ENTER CODE* is displayed. *OLD CODE* appears. Enter your old password, then NEW CODE appears in red. Enter a four-digit number as your new password. After you enter the number, *ENTER CODE* appears in blue. Reconfirm your password by entering it again.

If you forget your password, enter 4769 as your password and change it to a new one.

CH Lock (Channel Lock)

You can lock individual channels with this feature.

LOCK

ON: Turns on CH LOCK.

OFF: Turns off CH LOCK.

CH AIR: Select the channel you want to lock. You can use VOL ◁/▷ buttons or number buttons to input channel number.

*Note: "CH CABLE ***" is displayed under CABLE mode.*

CH LOCK

ON: If this is set to *ON,* the selected channel in the *CH LOCK* menu cannot be viewed.

OFF: LOCK is deactivated and any selected channel for *CH LOCK* can be viewed.

Downloaded from www.Manualslib.com manuals search engine

Using the P.LOCK menu (continued)



Setting V-Chip

If you have already set your password and you want to enter the P.LOCK menu, *ENTER CODE* appears in blue, as shown in Figure 1. Enter your password.

V-CHIP

ON: Turns on V-CHIP.
OFF: Turns off V-CHIP.

MPAA Rating

BLOCK prohibits the blocked channel. *VIEW* permits you to watch channels. If a high rating is set to *VIEW*, all the ratings below it will also be set to *VIEW*; if a low rating is set to *BLOCK*, all the ratings above it will also be set to *BLOCK*.

G: General Audiences
PG: Parental Guidance Suggested.
PG-13: Parents Strongly Cautioned.
R: Restricted.
NC-17: No one under 17 admitted.
X: For Adults.

TV Rating

Just as with the movie ratings, *BLOCK* prohibits the blocked channel. *VIEW* permits you to watch channels. If a high rating is set to *VIEW*, all the ratings below it will also be set to *VIEW*; if a low rating is set to *BLOCK*, all the ratings above it will also be set to *BLOCK*.

Y: All children.

Y7: Directed to older children.
The following item can be set for this rating:
FV: Fantasy violence.

G: General Audience.

PG: Parental Guidance suggested.
The following items can be set for this rating:
D: Suggestive Dialogue.
L: Strong language.
S: Sexual situation.
V: Violence.

14: Parents strongly cautioned.
The following items can be set for this rating:
D: Suggestive Dialogue.
L: Strong language.
S: Sexual situation.
V: Violence.

MA: Mature Audience only.
The following items can be set for this rating:

L: Strong language.
S: Sexual situation.
V: Violence.

Downloaded from www.Manualslib.com manuals search engine

To select the TIMER menu



Display ⟶ Highlight **TIMER** ⟶ Select



Using the TIMER menu

Clock

Press the number buttons to set the hour and minute.

Press the VOL ◁/▷ buttons to switch between AM and PM.

Timer

ON: Set the timer to be active.
OFF: Turn off the timer.

Note: The clock must be programmed before you can use the timer.

On Time

Press the number buttons to set the hour and minute.

Press the VOL ◁/▷ buttons to set AM or PM.

Note: ON-TIME will turn on the TV automatically at the preset time. TIMER must be set to ON for this feature to work.

On CH (Channel)

You can press the 0-9 number buttons or PROG. △/▽ buttons to select your desired channel.

Off Time

Press the number buttons to set the hour and minute.

Press the VOL ◁/▷ buttons to set AM or PM.

Note: OFF-TIME will turn off the TV automatically at preset time, TIMER must be set to ON for this feature to work.

Note: When you unplug the power cord, the time will be reset. You'll need to set the clock again.

Downloaded from www.Manualslib.com manuals search engine

To select the PRESET menu



Display ⟶ Highlight **PRESET** ⟶ Select



Using the PRESET menu

CH NO. (Channel Number)

Press the number buttons or VOL ◁/▷ buttons to select your desired channel.

CH (Channel)

ADDED: Adds the channel that you selected in *CH NO*.

DELETED: Deletes the channel that you selected in *CH NO*.

Antenna

AIR: Select to receive off-air antenna signals.

CABLE: Select to receive cable signals.

Auto Program

Searches for all available channels.

Note: TIMER, ON TIME, ON CH, and OFF TIME items in the TIMER submenu will be reset when AIR/CABLE modes are switched.

Downloaded from www.Manualslib.com manuals search engine

To select the EXTRA menu



Display ⟶ Highlight **EXTRA** ⟶ Select



Using the EXTRA menu

Closed Captioning

C1: Displays Caption 1.

C2: Displays Caption 2.

C MUTE: Caption is displayed when the volume is muted.

TEXT1: Displays TEXT 1.

TEXT2: Displays TEXT 2.

OFF: Turns off Closed Captioning.

Tips:

Captions prepared for TV programs can be pre-recorded (movie, daytime dramas etc.). This type of caption is normally 1 or 2 lines of text.

Text can include: captioned program listings, farm news, sports reports and news reports for hearing impaired persons or general wire-service news. This type of caption does not generally relate to the program. The displays may be several lines of text information at a time.

Language

Allows you to display the menu languages in English, Spanish, or French.

Background

With this option, you can choose to display a blue background when no signal is present.

Downloaded from www.Manualslib.com manuals search engine

Troubleshooting

You can correct most problems you have with your product by consulting the following troubleshooting list. If you need service, please refer to the service centers in this user's guide or contact the store where you purchased this product.

TV Problems

TV does not operate.

- Make sure the power cord is plugged in.
- Try another AC outlet.
- Power is off ; check fuse or circuit breaker.

Poor sound or no sound.

- Station or CATV experiencing problems; tune to another station.
- Check sound adjustments (Volume and Mute).
- Check for source of possible interference.

Poor picture or no picture.

- Station or CATV experiencing problems; tune to another station.
- Check antenna or CATV connections; reorient antenna.
- Check for source of possible interference.
- Check picture adjustments.

Poor reception on some channels.

- Station or CATV experiencing problems; tune to another station.
- Station signal is weak; reorient antenna to receive weaker station.
- Check for sources of possible interference.

Poor color or no color.

- Station or CATV experiencing problems; tune to another station.
- Check picture adjustments.
- Make sure Antenna Mode is correct.
- Check antenna or CATV connections; reorient antenna.
- Check for sources of possible interference.

Picture wobbles or drifts.

- Station or CATV experiencing problems; tune to another station.
- CATV company is scrambling signal.
- Check antenna orientation.

No CATV reception.

- Check CATV connections.
- Make sure Antenna Mode is correct.
- Station or CATV system problems; try another station.

Horizontal or diagonal bars on screen.

- Check antenna connections and reorient antenna.
- Make sure Antenna Mode is correct.
- Check for source of possible interference.

No remote operation.

- Batteries are weak, dead or inserted improperly.
- Remote is out of range; move closer to TV.
- Make sure remote is aimed at sensor.
- Confirm no obstructions between remote and TV.
- Make sure power cord is plugged in.

TV shuts off.

- Sleep Timer is set.
- Power interrupted.

No reception above channel 13.

- Make sure Antenna Mode is correct.
- If using UHF antenna, check connections.

Specifications

Model:	21B042	14B042
Color System:	NTSC	NTSC
AC Power Input:	90-140V, 60Hz	90-140V, 60Hz
Power Consumption:	80 Watts	70 Watts
Audio Output:	2x2 Watts	2x1 Watts
Picture Tube: (measured diagonally)	21"	14"
Dimensions:	23.2" (W) x 17.9" (D) x 18.5" (H)	16.2" (W) x 14.6" (D) x 13.0" (H)
Weight:	48.7 lbs	40.1 lbs
Speaker:	18 ohm/7W	16 ohm/3W

Models:	21B042 & 14B042
Tuner Type:	181 Channel, Quartz PLL Frequency Synthesized
Remote Control:	24 Buttons, 2 x AAA Batteries
Receiving Channels:	VHF 2-13 UHF 14-89 CATV 01-125
Antenna Input Impedance:	75 ohm (VHF/UHF/CATV) Coaxial Input

Additional Jacks

Model:	21B042	14B042
Rear Video Output:	Yes	No
Rear Audio Output:	Yes	No
Headphone Output:	Yes	No

Downloaded from www.Manualslib.com manuals search engine

Limited Warranty - United States

What your warranty covers:

- Any defect in materials or workmanship.

For how long after your purchase:

- One year for labor and parts.
- The warranty for rental units begins with the first rental or 45 days from date of shipment to the rental firm, whichever comes first.

What we will do:

- Pay any Authorized RCA Service Center the labor charges to repair your unit.
- Pay any Authorized RCA Service Center for the new or, at our option, refurbished replacement parts required to repair your unit.

How you get service:

- Take your unit to any Authorized RCA Service Center. To identify your nearest Authorized RCA Service Center, consult your dealer.
- Show the Authorized Service Center Representative your evidence of purchase date or first rental.
- Pick up your unit when repairs are completed.

What your warranty *does not* cover:

- Customer instruction. (Your Owner's Manual provides information regarding operating instructions and user controls. For additional information, ask your dealer.)
- Installation and set-up service adjustments.
- Batteries.
- Damage from misuse or neglect.
- Products which have been modified or incorporated into other products.
- Products purchased or serviced outside the USA.
- Acts of nature, such as but not limited to lightning damage.

Product Registration:

- Please complete and mail the Product Registration Card packed with your unit. It will make it easier to contact you should it ever be necessary. The return of the card is not required for warranty coverage.

Limitation of Warranty:

- **THE WARRANTY STATED ABOVE IS THE ONLY WARRANTY APPLICABLE TO THIS PRODUCT. ALL OTHER WARRANTIES, EXPRESS OR IMPLIED (INCLUDING ALL IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE) ARE HEREBY DISCLAIMED. NO VERBAL OR WRITTEN INFORMATION GIVEN BY TTE TECHNOLOGY, INC., ITS AGENTS OR EMPLOYEES SHALL CREATE A GUARANTY OR IN ANY WAY INCREASE THE SCOPE OF THIS WARRANTY.**
- **REPAIR OR REPLACEMENT AS PROVIDED UNDER THIS WARRANTY IS THE EXCLUSIVE REMEDY OF THE CONSUMER. TTE TECHNOLOGY, INC. SHALL NOT BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OF THIS PRODUCT OR ARISING OUT OF ANY BREACH OF ANY EXPRESS OR IMPLIED WARRANTY ON THIS PRODUCT. THIS DISCLAIMER OF WARRANTIES AND LIMITED WARRANTY ARE GOVERNED BY THE LAWS OF THE STATE OF INDIANA. EXCEPT TO THE EXTENT PROHIBITED BY APPLICABLE LAW, ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE ON THIS PRODUCT IS LIMITED TO THE APPLICABLE WARRANTY PERIOD SET FORTH ABOVE.**

How state law relates to warranty:

- This warranty gives you specific legal rights and you may have other rights that vary from state to state.

If you purchased your product outside the United States:

- This warranty does not apply. See your dealer for warranty information.

Service calls, which do not involve defective materials or workmanship, are not covered by this warranty.

Costs of such service calls are the sole responsibility of the purchaser.

Limited Warranty - Other Countries

Outside of Mexico, Chile and the United States please contact your selling dealer for any warranty.

Downloaded from www.Manualslib.com manuals search engine

RCA

POLIZA DE GARANTIA

TTE México S.A. de C.V. garantiza este producto en todas sus partes y mano de obra, contra cualquier defecto de fabricación y funcionamiento, a partir de la fecha de entrega al cliente final. Bajo el siguiente término:

Producto	Partes	Mano de Obra
Televisores c/cinescopio de 36,6 cm. (14 pulgadas) y menores	2 años cinescopio. 1 año otras partes.	1 año
Televisores c/cinescopio de 48,3 cm. (19 pulgadas) y mayores.	2 años cinescopio. 1 año otras partes.	1 año
Televisión de Proyección	1 año	1 año
Videocaseteras	1 año	1 año
Videocámaras	1 año	1 año
Equipos de Audio	1 año	1 año
Reproductor de DVD	1 año	1 año
Accesorios	1 año	1 año

CONDICIONES

1. Para ser efectiva esta garantía se requiere presentar esta póliza o factura de compra debidamente sellada y requisitada, junto con el producto en cualquiera de nuestros Centros de Servicios Autorizados, (que se indican en la hoja anexa), o en el lugar donde fué adquirido.
2. TTE México se compromete a reparar y/o reponer las piezas y componentes defectuosos sin cargo al consumidor, o en case de que a criterio de dicha empresa no sea posible la reparación, cambiar por un nuevo, exactamente del mismo modelo o su similar. Los gastos de transportación dentro de la red de servicios, que se deriven del cumplimiento de esta póliza de garantía, serán cubiertos por TTE México.
3. Todos los productos deberán ser llevados a cualquier Centro de Servicio Autorizado, excepto los televisores con pantalla de 63,5 cm (25 pulgadas) o más, los cuales serán reparados en el domicilio del cliente.
4. El tiempo de reparación en ningún caso será mayor a 30 días, contados a partir de la recepción del producto en el Centro de Servicio Autorizado.
5. Para la adquisición de partes y accesorios, contactar al 01-800-1117221 o acudir a TTE México.

NOTAS:

En caso de extravío de la póliza, el consumidor podrá recurrir a su distribuidor para su reposición, previa presentación de la factura o nota de compra.

Para su comodidad, solicite informes sobre la localización del Centro de Servicio Autorizado más cercano a su domicilio, llamando al:

01-800-1117221

No. de Póliza: _____

TTE México S.A. de C.V.
Álvaro Obregón No. 151. Piso 13, Col. Roma.
México, D.F. C.P. 06700; Apartado Postal 41-540

DATOS DEL PRODUCTO

PRODUCTO: _____

MODELO: _____ **NO. DE SERIE** _____

DATOS DEL CLIENTE

EXPEDIDA A: _____

DIRECCION: _____

_____

NOMBRE: _____

DIRECCION: _____

_____

FECHA DE COMPRA: _____
SELLO Y FIRMA DEL VENDEDOR

ESTA GARANTIA NO TIENE VALIDEZ EN LOS SIGUIENTES CASOS

- Cuando el producto se hubiese utilizado en condiciones distintas a las normales.
- Cuando el producto no hubiese sido operado de acuerdo al instructivo de uso que se le acompaña.
- Cuando el producto hubiese sido alterado o reparado por personas no autorizadas por TTE México S.A de C.V.

Downloaded from www.Manualslib.com manuals search engine

Other Information

RED NACIONAL DE SERVICIO

RCA

Centro de Servicios Autorizados Express
(servicio en 24 horas)

México, D.F.
Digital Service Vallejo
Av. 3 A No. 12, Local 2
Col. Santa Rosa
México, D.F.
Tels (55) 53677347 y 53677349
Tel/Fax (55) 53889621

Guadalajara, Jal.
Servicio Especializado de Jalisco
Enrique Díaz de León No. 821
Col. Sagrada Familia
Guadalajara, Jal.
Tel (33) 31267431, 31267430
38253229, 38258262

Monterrey. N.L.
Audio Estéreo Aguilar
Gral. Zuazua 738 Nte.
Col. Centro
Monterrey. N.L.
Tel (81) 83724989
83755884

AGUASCALIENTES
Electrónica JIMSA
Av. Adolfo López Mateos No. 230 Ote.
Col. Centro
Aguascalientes, Ags. C.P.2000
Tel (449) 915 5181; 978 0757
Fax (449) 915 8100

BAJA CALIFORNIA NORTE
Electrónica General Internac
Blvd. Insurgentes No. 16174, Loc. 2AC.
Plaza de Abastos Los Almos
Tijuana, BCN C.P. 22440
Tel/Fax (664) 6212215

Baja Electronics
Hacienda de Corralejo No. 2099
Col. Hidalgo
Mexicali, B.C.N. C.P. 21389
Tel/Fax (686) 5619818, 5619808

BAJA CALIFORNIA SUR
Digital Sound
16 de Septiembre No. 390
Col. Centro
La Paz, Baja California Sur
Tel/Fax (612) 1232017

Video Servicio Beluz
Carretera a todos Santos No. 32
Col. Infonavit Las Brisas.
Los Cabos San Lucas, BCS C.P. 23410
Tel/Fax (624) 14313 65

CAMPECHE
Videoservicio
Av. López Mateos No. 24
Col. Barrio Sn. Román.
Campeche, Camp. C.P.24040
Tel (981) 816 3333
Fax (981) 811 0669

CHIAPAS
KC Video
10a. Norte Oriente No. 153A
Col. Centro
Tuxtla Gutiérrez, Chis. C.P. 29000
Tel/Fax (961) 618 1908;
Tel (961) 618 3643

Serv. Elec. Especializado
Cuahutémoc No. 2A
Col. Centro, C.P. 29200
San. Cristóbal de las Casas, Chis.
Tel/Fax (967) 6781355

Ele Aplicada Serv Digitales
4a. Av., Sur No. 51
Col. Centro, C.P. 30700
Tapachula, Chis.
Tel (962) 6269998
Fax (962) 6256953

CHIHUAHUA
Zener Electrónica
Av.Teófilo Borunda Sur # 300
Col. Centro
Chihuahua, Chih. C.P. 31000
Tel/Fax (614) 4371901
Tel (614) 4371902

Eletrónica Union
Laguna de Tamiahua 7255 local 13
Col.Infonavit San Lorenzo. C.C.Calesa
Cd.Juárez, Chihuahua C.P.32420
Tel/Fax (656) 6177890

Electrónica Tony
Av. Tercera Pte. No. 213
Col. Centro
Cd. Delicias, Chihuahua
Tel/Fax (639) 4743026

Taller Electrónico Tony
20 de Noviembre No. 1521
Col. Centro.
Cd. Camargo, Chihuahua. C.P.
Tel/Fax (639) 4743026

COAHUILA
Electrónica Profesional
Blvrd. Francisco Coss No. 450-1
Col. Centro
Saltillo, Coah C.P. 25000
Tel/Fax (844) 4123044

Audio y Video Electrónica
Miguel Blanco 307-A
Col Zona Centro.
Monclova, Coahuila. C.P. 25700
Tel/Fax (866) 6339406

Vacom
Av. Morelos 1016 ote.
Col. Centro
Torreón, Coah. C.P. 27000
Tel 01 871 718 39 05, 7 22 15 51
Fax 01 871 718 11 98

Serel. S.A.
Calle Nueva No.307
Col. González
Piedras Negras,
Coahuila. C.P.26000
Tel/Fax (878) 7827104

Multiservicios del Norte
5 de Mayo 295 Sur.
Col. Centro
Sabinas, Coahuila. C.P. 26700
Tel/Fax (861) 6126431

COLIMA
TV. Servicio Saturno
Nigromante No. 136 Altos
Col. Centro
Colima, Col. C.P. 28000
Tel/Fax (312) 3145554, Tel (312) 3145000

Centro De Rep. Electrónicas
Tucanes # 66 Barrio 5
Col. Valle de las Garzas.
Manzanillo, Col. C.P.
Tel (314) 3323004
Tel/Fax (314) 3354667

DISTRITO FEDERAL
Laboratorio Electrónico.
Retorno 52 Cecilio Róbelo, Edif 1, Loc16-02
Col. Jardín Balbuena
México, D.F.
Tel/Fax (55) 57620264, 57626494

ADE Electrónica
Corea No. 79
Col. Romero Rubio
México D.F. C.P. 15400
Tel/Fax (55) 57027223

Electro Digital.
Av. Tl·huac No. 4798
Barrio de S. Sebastián Tulyehualco Xoch.
México D.F.
Tel/Fax (55) 21614639

SIMEL
Río Churubusco No. 2215
Col. Agrícola Oriental
México, D.F. C.P. 08500
Tel (55) 57563785, Fax (55) 57560883

CICOSA
Ahuizotl # 94
Col. La Preciosa
México, D.F. C.P.02460
Tel 5347 0302, 5561 6943
Fax 5532 0663

Novatron.
Diag. San Antonio No. 1213
Col. Narvarte
México, D.F. C.P. 03020
Tel (55) 56390812
Fax (55)56391184

Premium Technical Support
Calzada Taxqueña # 1423
Col. Campestre Churubusco
México, D.F.
Tel 53362467

Centro de Servicio Electrónico
Nicolás San Juan 806 P.B.
Col. Del Valle
México, D.F. C.P.03100
Tel 5536-2575, 55367103
Fax 5687-1305

DURANGO
Macroservicios.
Calle Patoni No. 105 sur.
Col. Centro
Durango, Dgo.
Tel/Fax (618) 812 26 86

ESTADO DE MEXICO
Digital Service Prensa
Prensa No. 1253
Col. Prensa Nal. Ind. Vallejo.
Tlanepantla, E.D.M. C.P. 54170
Tel (55) 55877599 y 55673972
Fax (55) 55878971

SHUREE Electrónica
Av. De los Maestros No. 113A
Col. Pensiones, C.P. 50060
Toluca, EDM.
Tel (722) 2149330, 2133424

TV Servideo
Oriente 9 No. 182
Col. Reforma
Cd. Neza, Edo. De Méx. C.P. 57840
Tel (55) 58572547
Fax (55) 58576399

Electrónica CIS
Reforma No. 36
Col. Centro
Chalco, Edo. de Méx. C.P. 56600
Tel/Fax (55) 3092 3060

GUANAJUATO
Tecnología Electrónica
Blvd. Adolfo López Mateos No. 2820B
Col. Haciendas El Rosario
León, Gto. C.P. 37130
Tel/Fax (477) 4702701

Electrónica Siglo XXI
Naranjo No. 950
Col. Flores Magón.
Irapuato, Guanajuato. C.P. 36180
Tel/Fax (462) 626 9823, 660 1238

Tele Servicio Chucho.
Blv Adolfo López Mateos No 510 Pte
Col. Centro, C.P. 38000
Celaya, Gto.
Tel/Fax (461) 6130591

Tele Radio Ortega.
Av. 16 de Septiembre No. 1076
Col. Centro, C.P. 38600
Acambaro, Gto.
Tel/Fax (417) 1720780

GUERRERO
Nueva Elec. Auditron
Aquiles Serdán No. 14B
Col. Centro
Acapulco, Gro. C.P. 039300
Tel (744) 4826242
Tel/Fax (744) 4832062

RED NACIONAL DE SERVICIO

RCA

Ingeniería Electrónica
Antonia Nava de Catalán No.17
Col. Centro
Chilpancingo, Gro. C.P.39000
Tel (747) 4717273
Tel/Fax (747) 4948365

HIDALGO
Servicio Electrónica Avanzada
Plaza Comercial Quinta Bonita Loc.11
Fraccionamiento Quinta Bonita
Pachuca, Hgo. C.P. 42083
Tel/Fax (771) 7132436

Electrónica Especializada
Independencia No. 102 Loc. C
Col. Centro, C.P. 43600
Tulancingo, Hgo,
Tel/Fax (775) 7552654 Tel (775) 7539120

JALISCO
Serv. Esp. De Jalisco
Ignacio Ramírez No. 567
S.H. Sta. Teresita
Guadalajara, Jal. C.P. 44200
Tel/Fax (33) 38253229 Tel (33) 38270721

Electrónica Integral
Candelaria No. 202, Esq. Analco
Col. Sta. María
Puerto Vallarta, Jal. C.P. 48348
Tel (322) 2243736
Tel/Fax (322) 2248590

Setesa
5 de Febrero No. 2786
Col. Rancho Blanco
Tlaquepaque, Jalisco. C.P. 44890
Tel (33) 36354404
Tel/Fax (33) 36351875

MICHOACAN
Alka Electrónica
García de León No. 271
Col. Chapultepec Sur.
Morelia, Mich. C.P. 58260
Tel (443) 3145521, 3159036
Tel/Fax (443) 3159425

Centro Electrónico
Justo Mendoza No. 12
Col. Centro
Uruapán, Mich. C.P. 60000
Tel (452) 5243778, 5240838
Tel/Fax (452) 5245909

Multiserv Prof. Zamora
Colón No. 181-1 Ote.
Col. Centro
Zamora, Mich. C.P. 59600
Tel/Fax (351) 5155416

MORELOS
Electrónica Hertz
Insurgentes No. 190
Col. Emiliano Zapata
Cuautla, Mor. C.P. 62744
Tel/Fax (735) 3538410

Electrónica Hertz
Libertad No. 130.
Col. Carolina
Cuernavaca, Mor. C.P. 62190
Tels (777) 3139092, 3119127

NUEVO LEON
Audio Estéreo Aguilar
Gral. Zuazua 738 Nte.
Col. Centro
Monterrey, Nvo. León. CP. 64000
Tels (81) 83724989, 83755440
Tel/Fax (81) 83755884

Técnica Especializada
Diego Díaz de Berlanga # 206
Col. Residencial Nogalar C.P.66480
San Nicolás de los Garza, Nvo.León.
Tel (81) 86762799 y 80402747
Fax (81) 80402747

Teleservicio Murillo
Pino Suarez # 501 Sur.
Col. Centro
Cd. Linares, Nvo León. C.P. 67700
Tel/Fax (821) 2126650

NAYARIT
Electrónica Show
San Luis No. 118 sur
Col. Centro
Tepic, Nay. C.P. 63000
Tel/Fax (311) 2145800

OAXACA
E-Prom Lab.Electrónico
Modesto Díaz No.403
Col.Ricardo Flores Magón,
por volcanes
Oaxaca, Oax. C.P.68020
Tel/Fax (951) 5201189

Telestar
Av.Libertad No. 1557
Col. La Piragüa
Tuxtepec, Oaxaca
Tel/Fax (287) 8752544

PUEBLA
Serv. Express Electrónico
Prol. Reforma No. 6908A
Col. La Libertad
Puebla, Pue. C.P. 72130
Tel (222) 2497819
Tel/Fax (222) 2313293

Centro de Servicio P.C.
Av. Independencia Pte. No. 407
Col. Centro
Tehuacán, Puebla C.P. 75700
Tel/Fax (238) 3823835

QUERETARO
Blauton Industrial
Av. Universidad No. 44B
Col. Pathe
Querétaro, Qro. C.P. 76020
Tels (442) 2232266, 2234934
Tel/Fax (442) 2232267

QUINTANA ROO
Electrónica Beta
Av. Sun Yax Chen No. 43 Loc. 4
Col. Centro
Cancún, Q. Roo. C.P. 77508
Tel (998) 8845412
Tel/Fax (998) 8873813

Electrónicos y Mas
Ignacio Zaragoza No. 204-A
Col. Centro. C.P. 77000
Chetumal, Q. Roo
Tels (983) 8326663, 8324622
Fax (983) 8326014

SAN LUIS POTOSI
Electrónica Especializada
Nicolás Zapata # 1015-A
Col. Tequisquiapán
San Luis Potosí, SLP. C.P. 78250
Tel (444) 8176279
Tel/Fax (444) 8176279

Estéreo Car
Negrete No. 612
Col. Centro
Cd. Valles, SLP. C.P. 79000
Tel/Fax (481) 3820651

SINALOA
Serv. Electrónico del Pacífico
Mariano Escobedo No. 1022
Col. Centro
Mazatlán, Sin. C.P. 82000
Tel/Fax (669) 9820155

Reparaciones Electrónicas
J.Jose Ríos No. 178 ote.
Col. Miguel Alemán.
Culiacán Sinaloa. C.P. 80200
Tel/Fax (667) 7168132,
(667) 7165145

Electrónica Morelos.
Morelos No. 201 ote
Col. Centro.
Los Mochis, Sinaloa. C.P. 81200
Tel/Fax (668) 8120588

SONORA
Wong's Electrónicos
12 de Octubre No.116 Esq.Q.Roo.
Col. San Benito
Hermosillo, Son. C.P. 83180
Tel (662) 2105495
Tel/Fax (662) 2100586

Dasetronik.
Guerrero No. 308-A este.
Col. Centro.
Navojoa, Sonora. C.P. 85800
Tel (642) 4224064
Fax (642) 4213664

Audio Video Electrónica
Av. Zaragoza No. 516 pte.
Col. Centro.
Cd. Obregón, Sonora. C.P. 85000
Tel (644) 4143828
Fax (644) 4147575

Electrónica Universal.
Calle 29 Av. Alfonso Idberry No. 401
Col. Centro
Cd. Guaymas, Sonora. C.P. 85400
Tel/Fax (622) 2229411

TABASCO
Elec. Sigma de Tabasco
Av. Gregorio Méndez No. 2819
Col. Atasta
Villahermosa, Tab. C.P. 86100
Tel (993) 3545410
Tel/Fax (993) 3540033

TAMAULIPAS
Electrónica Digital
Independencia No. 112 esq. 11
Col. Centro
Matamoros, Tamps. C.P. 88000
Tel/Fax (868) 8135013

Centro de Servicio Lugo
Rosalinda Guerrero No. 285
Col. Prol. Longoria
Reynosa, Tamps. C.P. 88699
Tel/Fax (899) 9249243

Esp. Electrónicas
Matamoros Poniente 225
Col. Centro
Cd. Victoria, Tamps. C.P. 87000
Tel (834) 3125193
Fax (834) 3125193

Micronics
Calle 10 No. 607.
Col. Jardín 20 de Noviembre
Madero, Tamps. C.P. 89440
Tel (833) 2159689
Fax (833) 2103882

Laboratorio Electrónico
Washington 3142
Col. Juárez (Centro)
Nuevo Laredo, Tamps. C.P. 88000
Tel (867) 7149592
Tel/Fax (867) 7149852

Electrónica Emmanuel
Obregón No. 206 Pte.
Zona Centro
Cd. Mante, Tamaulipas. C.P. 89800
Tel/Fax (831) 2329081

TLAXCALA
Sexel. De Tlaxcala
Av. Revolución No. 33 Local A.
Col. Atenpán
Tlaxcala, Tlax.
Tel/Fax (246) 462 9660

VERACRUZ
Serv Técnicos Prof.
Av. 13 No. 400 Esq.
Calle 4
Col. Bella Vista
Córdoba, Ver. C.P. 94500
Tel (271) 7127322
Fax (271) 7122539

Electrónica Arizona
Acosta No. 9
Zona Centro
Jalapa, Ver. C.P. 91000
Tel (228) 8903561 y 62

Electrónica Digital
Av. Juárez No. 516
Col. 27 de Septiembre
Poza Rica, Ver. C.P. 93320
Tel (782) 8229899
Tel/Fax (782) 8236949

Electrónica DICA
F. del Paso y Troncoso No. 908
Col. Centro
Veracruz, Ver. C.P. 91700
Tel (229) 9312296
Tel/Fax (229) 9312033

Seguridad Plus.
SUR 15 # 210 ENTRE ORIENTE 4 Y 6
Col. Centro
Orizaba, Ver. C.P.94300
Tel/Fax (272) 7247676

YUCATAN
Servicentro
Calle 70 No. 443 x calle 49 dept.5
Col. Centro
Mérida, Yuc. C.P. 97000
Tel (999) 9285428 y 9233997
Tel/Fax (999) 9285905

ZACATECAS
Electrónica Mario.
Morelos
Poniente No. 1214
Col. Centro
Zacatecas, Zac.
C.P. 98000
Tel/Fax (492) 9227561

Downloaded from www.Manualslib.com manuals search engine

Downloaded from www.Manualslib.com manuals search engine

Visit the RCA website at www.rca.com

Please do not send any products to the Indianapolis address listed in this manual or on the carton. This will only add delays in service for your product.

IMPORTER (for Mexico only):
TTE México, S.A. de C.V.
Álvaro Obregón No. 151. Piso 13
Col. Roma. Delegación Cuauhtémoc
C.P. 06700 México D.F.
Teléfono: 52-55-11-020360
RFC: TME-040528-7S2

EXPORTER:
TTE Technology, Inc.
10330 North Meridian Street
Indianapolis, IN 46290

©2004 TTE Technology, Inc.
Trademark(s)® Registered
Marca(s) Registrada(s)
Printed in Mexico
TOCOM 1640641B

Downloaded from www.Manualslib.com manuals search engine